

# **WinMETER 5.1 INSTALLATION INSTRUCTIONS**

## **INTRODUCTION**

**WinMETER 5.1** is custom Windows™ software program developed specifically for the data logging test equipment manufactured by Explorer Technology Group. This includes data logging voltmeters (DLV & CTL series), DSG-Series hydrometers, and DMA-Series hydrometers data logging module (ETG Version).

The software allows cell test data to be stored in a convenient database. It will display and print reports that include tabulated data, statistical analysis and graphs.

If you have already purchased any of our data logging test equipment it will be compatible with this software.

**Note: The older DLV50 unit will not work with this Winmeter 5.1 software. That will include serial # 2013010 and older. Also, this software will install over Winmeter 5.0, so if you have a PC designated to work with the older DLV50, please do not install Winmeter 5.1.**

## **SYSTEM REQUIREMENTS**

- A PC with a 1GHz Intel or AMD processor
- Intel Pentium D or faster processor
- 512MB of RAM
- Available USB Port or Serial Port
- Windows XP Service Pack 2 or later, 32-bit editions of Windows Vista, or Windows 7, Windows 8
- 64-bit editions of Windows Vista or Windows 7 or Windows 8

### **Prerequisites:**

- Microsoft .NET Framework 3.5
- This software is required for the Winmeter 5.1 software to install and run correctly.
- A copy of this software has been included in the install folder.

## **INSTALLATION PROCEDURE**

Step A: Insert the **WinMETER 5.1** installation CD into CD-ROM drive.

Step B: Run setup.exe from the installation CD.

## **CONFIGURATION**

Before any data can be downloaded into the PC, the software must be configured for your system. The installer must enter the following information into the "Configuration" menu selection.

**Com Port Selection:** Select the number of the com port (1-25) that you will connect to the **RS232** downloading cable.

**Enable/Disable USB Auto Start:** Select this option if you want to enable or disable Winmeter 5.0 from automatically launching when connecting any **USB** capable ETG test instrument. **Restart** the PC to initiate the change.

For any questions regarding software installation, downloading or registration please contact Explorer Technology Group at:  
770-433-8551 (ph) or 770-405-8149 (fax)